THERMAL CONDUCTIVITY OF LIQUIDS

This table gives the thermal conductivity of some common liquids at temperatures between -25 and 100°C. All values are given in units of watts per meter kelvin (W/m K). Values refer to nominal atmospheric pressure (about 100 kPa); when an entry is given at a temperature above the normal boiling point of the substance, the pressure is understood to be the saturation vapor pressure at that temperature.

Substances are arranged by molecular formula in the modified Hill order, with compounds not containing carbon preceding those that do contain carbon.

The values for water, benzene, toluene, heptane, and dimethyl phthalate are particularly well determined and can be used for calibration purposes.

REFERENCES

- 1. Daubert, T. E., Danner, R. P., Sibul, H. M., and Stebbins, C. C., *Physical and Thermodynamic Properties of Pure Compounds: Data Compilation*, extant 1994 (core with 4 supplements), Taylor & Francis, Bristol, PA (also available as database).
- 2. Marsh, K. N., Ed., Recommended Reference Materials for the Realization of Physicochemical Properties, Blackwell Scientific Publications, Oxford, 1987.

Molecular		Thermal conductivity in W/m K						
formula	Name	-25° C	0°C	25°C	50°C	75°C	100°C	
Cl ₄ Si	Silicon tetrachloride			0.099	0.096			
$H_2^{7}O$	Water		0.5610	0.6071	0.6435	0.6668	0.6791	
Hg	Mercury	7.25	7.77	8.25	8.68	9.07	9.43	
CCl₄	Tetrachloromethane		0.104	0.099	0.093	0.088		
CS_2	Carbon disulfide		0.154	0.149				
CHCl ₃	Trichloromethane	0.127	0.122	0.117	0.112	0.107	0.102	
CH_2Br_2	Dibromomethane	0.120	0.114	0.108	0.103	0.097		
CH ₄ O	Methanol	0.214	0.207	0.200	0.193			
C_2Cl_4	Tetrachloroethylene		0.117	0.110	0.104	0.097	0.091	
C ₂ HCl ₃	Trichloroethylene	0.133	0.124	0.116	0.108	0.100		
C ₂ H ₃ Cl ₃	1,1,1-Trichloroethane		0.106	0.101	0.096			
C_2H_3N	Acetonitrile	0.208	0.198	0.188	0.178	0.168		
$C_2H_4O_2$	Acetic acid		******	0.158	0.153	0.149	0.144	
C ₂ H ₅ Cl	Chloroethane	0.145	0.132	0.119	0.106	0.093	0.1	
C_2H_5NO	N-Methylformamide	0.1 15	0.132	0.203	0.201	0.199	0.196	
C_2H_6O	Ethanol		0.176	0.169	0.162	0.177	0.170	
$C_2H_6O_2$	Ethylene glycol		0.256	0.256	0.256	0.256	0.256	
$C_2H_6O_2$ C_2H_7NO	Ethanolamine		0.230	0.299	0.286	0.274	0.261	
C_3H_5ClO	Epichlorohydrin	0.142	0.137	0.131	0.125	0.119	0.114	
C_3H_6O	Acetone	0.142	0.169	0.161	0.123	0.115	0.114	
$C_3H_6O_2$	Methyl acetate	0.174	0.164	0.153	0.143	0.133	0.122	
$C_3H_6O_2$ C_3H_7NO	<i>N,N</i> -Dimethylformamide	0.174	0.104	0.184	0.178	0.171	0.122	
C_3H_8O	1-Propanol	0.162	0.158	0.154	0.149	0.145	0.141	
C_3H_8O C_3H_8O	2-Propanol	0.102	0.141	0.135	0.129	0.143	0.141	
$C_3H_8O_2$	1,2-Propanediol	0.140	0.202	0.200	0.199	0.124	0.110	
$C_{3}H_{8}O_{2}$ $C_{3}H_{8}O_{3}$	Glycerol		0.202	0.292	0.295	0.198	0.300	
$C_3H_9O_3$ C_3H_9N	Trimethylamine	0.143	0.133	0.272	0.273	0.277	0.300	
C_4H_4O	Furan	0.142	0.134	0.126				
C_4H_4S	Thiophene	0.142	0.134	0.120	0.195	0.191	0.186	
C_4H_4S C_4H_6	2-Butyne	0.137	0.129	0.121	0.173	0.171	0.100	
C_4H_6 C_4H_8O	2-Butanone	0.157	0.123	0.145	0.139	0.133		
C_4H_8O C_4H_8O	Tetrahydrofuran	0.138	0.126	0.143	0.139	0.133		
$C_4H_8O_2$	1,4-Dioxane	0.132	0.120	0.120	0.114	0.135	0.123	
$C_4H_8O_2$ $C_4H_8O_2$	Ethyl acetate	0.162	0.153	0.139	0.147	0.135	0.123	
$C_4H_8O_2$ $C_4H_{10}O$	1-Butanol	0.102	0.158	0.154	0.133	0.120		
	Diethyl ether	0.150	0.138	0.134	0.149	0.110	0.100	
$C_4H_{10}O$	-	0.130	0.169		0.120		0.100	
C ₅ H ₅ N	Pyridine	0.142		0.165	0.101	0.158		
C_5H_8	Cyclopentene	0.143	0.136	0.129				
C_5H_{10}	1-Pentene	0.131	0.124	0.116				
C_5H_{10}	Cyclopentane	0.140	0.133	0.126	0.102	0.005	0.007	
C_5H_{12}	Pentane	0.132	0.122	0.113	0.103	0.095	0.087	
$C_5H_{12}O$	1-Pentanol	0.126	0.157	0.153	0.149	0.145	0.112	
C ₆ H ₅ Cl	Chlorobenzene	0.136	0.131	0.127	0.122	0.117	0.112	

THERMAL CONDUCTIVITY OF LIQUIDS (continued)

Molecular		Thermal conductivity in W/m K						
formula	Name	-25°C	0°С	25°C	50°C	75°C	100°C	
C_6H_6	Benzene			0.1411	0.1329	0.1247		
C_6H_6O	Phenol				0.156	0.153	0.151	
$C_{6}H_{10}$	Cyclohexene	0.142	0.136	0.130	0.124	0.118		
$C_6H_{10}O$	Mesityl oxide	0.170	0.163	0.156	0.149	0.142	0.134	
C_6H_{12}	Cyclohexane			0.123	0.117	0.111		
C_6H_{12}	1-Hexene	0.137	0.129	0.121	0.113			
$C_6H_{12}O$	Cyclohexanol			0.134	0.131			
$C_6H_{12}O$	2-Hexanone	0.151	0.145	0.139	0.133	0.127	0.121	
$C_{6}H_{14}$	Hexane	0.137	0.128	0.120	0.111	0.102	0.093	
$C_6H_{14}O$	1-Hexanol	0.159	0.154	0.150	0.145	0.141	0.137	
C ₇ H ₆ O	Benzaldehyde			0.151	0.141	0.131	0.121	
C_7H_8	Toluene	0.1461	0.1386	0.1311	0.1236	0.1161		
C_7H_8O	Anisole	0.170	0.163	0.156	0.150	0.143	0.136	
C_7H_{16}	Heptane	0.1378	0.1303	0.1228	0.1152	0.1077		
$C_7H_{16}O$	1-Heptanol		0.166	0.159	0.153	0.147	0.141	
C_8H_8	Styrene	0.148	0.142	0.137	0.131	0.126	0.120	
C_8H_{10}	Ethylbenzene			0.130	0.124	0.118	0.112	
C_8H_{10}	o-Xylene			0.131	0.126	0.120	0.114	
C_8H_{10}	m-Xylene			0.130	0.124	0.118	0.113	
C_8H_{10}	<i>p</i> -Xylene			0.130	0.124	0.118	0.112	
C_8H_{18}	Octane	0.143	0.135	0.128	0.120	0.113	0.106	
$C_8H_{18}O$	1-Octanol		0.168	0.161	0.154	0.147	0.141	
C_9H_{12}	Cumene			0.128	0.120	0.112	0.107	
C_9H_{12}	Mesitylene	0.147	0.141	0.136	0.130	0.124	0.118	
C_9H_{20}	Nonane	0.144	0.138	0.131	0.124	0.118	0.111	
$C_9H_{20}O$	1-Nonanol		0.166	0.161	0.155	0.149	0.143	
$C_{10}H_{10}O_4$	Dimethyl phthalate		0.1501	0.1473	0.1443	0.1409	0.1373	
$C_{10}H_{14}$	<i>p</i> -Cymene	0.132	0.127	0.122	0.117	0.112	0.107	
$C_{10}H_{22}$	Decane	0.144	0.138	0.132	0.126	0.119	0.113	
$C_{10}H_{22}O$	1-Decanol			0.162	0.156	0.150	0.145	
$C_{11}H_{24}$	Undecane			0.140	0.135	0.129	0.123	
$C_{12}H_{10}O$	Diphenyl ether				0.139	0.135	0.131	
$C_{12}H_{26}$	Dodecane		0.157	0.152	0.146	0.140	0.135	
$C_{12}H_{26}O$	1-Dodecanol			0.146	0.142	0.139	0.135	
$C_{13}H_{28}$	Tridecane			0.137	0.132	0.127	0.122	
$C_{14}H_{30}$	Tetradecane			0.136	0.131	0.126	0.121	
$C_{14}H_{30}O$	1-Tetradecanol				0.167	0.162	0.157	
$C_{16}H_{22}O_4$	Dibutyl phthalate	0.144	0.140	0.136	0.133	0.129	0.125	
$C_{16}H_{34}$	Hexadecane			0.140	0.135	0.130	0.125	
$C_{18}H_{38}$	Octadecane				0.146	0.142	0.137	