## DEPENDENCE OF BOILING POINT ON PRESSURE

The normal boiling point of a liquid is defined as the temperature at which the vapor pressure reaches standard atmospheric pressure, 101.325 kPa. The change in boiling point with pressure may be calculated from the representation of the vapor pressure by the Antoine Equation,

$$\ln p = A_1 - A_2/(T + A_3)$$

where p is the vapor pressure, T the absolute temperature, and  $A_1$ ,  $A_2$ , and  $A_3$  are constants. This table, which has been calculated using the Antoine constants in Reference 1, gives values of  $\Delta t/\Delta p$  for a number of liquids, in units of both °C/kPa and °C/mmHg. The correction to the boiling point is generally accurate to 0.1 to 0.2 °C as long as the pressure is within 10% of standard atmospheric pressure.

A slightly less accurate estimate of  $\Delta t/\Delta p$  may be obtained from the Claussius-Clapeyron equation, with the assumption that the change in volume upon vaporization equals the ideal-gas volume of the vapor. This leads to the equation

$$\Delta t/\Delta p = RT_b^2/p_0 \Delta_{\text{vap}} H(T_b)$$

where R is the molar gas constant,  $p_0$  is 101.325 kPa,  $T_b$  is the normal boiling point temperature (absolute), and  $\Delta_{\text{vap}}H(T_b)$  is the molar enthalpy of vaporization at the normal boiling point. Values of the last quantity may be obtained from the table "Enthalpy of Vaporization" in Section 6.

## REFERENCE

 Lide, D.R., and Kehiaian, H.V., CRC Handbook of Thermophysical and Thermochemical Data, CRC Press, Boca Raton, FL, 1994, pp. 49-59.

	$t_{ m b}$	$\Delta t/\Delta p$			$t_{ m b}$	$\Delta t/\Delta p$	
Compound	$^{\circ}\mathbf{C}$	°C/kPa	°C/mmHg	Compound	$^{\circ}\mathbf{C}$	°C/kPa	°C/mmHg
Acetaldehyde	20.1	0.261	0.0348	1-Hexanol	157.6	0.318	0.0424
Acetic acid	117.9	0.324	0.0432	Hydrogen fluoride	20.1	0.276	0.0368
Acetone	56.0	0.324	0.0432	Iodomethane	42.5	0.291	0.0388
Acetonic	81.6	0.207	0.0421	Isobutane	-11.7	0.254	0.0339
Ammonia	-33.33	0.198	0.0421	Methanol	64.6	0.251	0.0335
Aniline	184.1	0.178	0.0504	Methyl acetate	56.8	0.282	0.0376
Anisole	153.7	0.370	0.0489	Methyl formate	31.7	0.582	0.0776
Benzaldehyde	179.0	0.392	0.0523	<i>N</i> -Methylaniline	196.2	0.396	0.0528
Benzene	80.0	0.372	0.0323	<i>N</i> -Methylformamide	199.5	0.371	0.0495
Bromine	58.8	0.300	0.0420	Nitrobenzene	210.8	0.418	0.0557
Butane	-0.5	0.267	0.0356	Nitromethane	101.1	0.320	0.0427
1-Butanol	117.7	0.278	0.0330	1-Octanol	195.1	0.360	0.0480
Carbon disulfide	46.2	0.304	0.0405	Pentane	36.0	0.289	0.0385
Chlorine	-34.04	0.224	0.0299	1-Pentanol	137.9	0.296	0.0395
Chlorobenzene	131.7	0.365	0.0487	Phenol	181.8	0.349	0.0465
1-Chlorobutane	78.6	0.321	0.0428	Propane	-42.1	0.224	0.0299
Chloroethane	12.3	0.262	0.0349	1-Propanol	97.2	0.261	0.0348
Chloroethylene	-13.3	0.241	0.0321	2-Propanol	82.3	0.247	0.0329
Cyclohexane	80.7	0.328	0.0437	Pyridine	115.2	0.340	0.0453
Cyclohexanol	160.8	0.344	0.0459	Pyrrole	129.7	0.330	0.0440
Cyclohexanone	155.4	0.382	0.0509	Pyrrolidine	86.5	0.309	0.0412
Decane	174.1	0.388	0.0517	Styrene	145.1	0.369	0.0492
Dibutyl ether	140.2	0.363	0.0484	Sulfur dioxide	-10.05	0.221	0.0295
Dichloromethane	39.6	0.276	0.0368	Tetrachloroethylene	121.3	0.354	0.0472
Diethyl ether	34.5	0.278	0.0371	Tetrachloromethane	76.8	0.325	0.0433
Dimethyl sulfoxide	189.0	0.379	0.0505	Toluene	110.6	0.353	0.0471
1,4-Dioxane	101.5	0.321	0.0428	Trichloroethylene	87.2	0.330	0.0440
Dipropyl ether	90.0	0.326	0.0435	Trichloromethane	61.1	0.302	0.0403
Ethanol	78.2	0.249	0.0332	Trimethylamine	2.8	0.248	0.0331
Ethyl acetate	77.1	0.300	0.0400	Water	100.0	0.276	0.0368
Ethylene glycol	197.3	0.331	0.0441	o-Xylene	144.5	0.373	0.0497
Heptane	98.5	0.336	0.0448	m-Xylene	139.1	0.368	0.0491
Hexafluorobenzene	80.2	0.305	0.0407	<i>p</i> -Xylene	138.3	0.369	0.0492
Hexane	68.7	0.314	0.0419				